

## Dust Cap Installation

For the installation of your new dust caps you will need a set of long needle nose pliers, the dust caps (washers attached).



Position the needle nose pliers around the locking collar while ensuring the needle nose pliers are well-seated into the collar teeth. Gently but firmly turn the collar counter clockwise. Once free, remove the collar by hand.



Position the needle nose pliers into the teeth of the locking collar and firmly tighten the collar.



Install dust caps (washer end) over the connector and carefully reinstall the locking collar. This should thread easily until seated against the dust cap washers.



Congratulations on installing your new dust caps. They will allow you to protect your camera connectors while not in use and under extreme environmental conditions.

ZDOC-PRJ100-IG-0001 Rev1  
Rev July 2016